




VERY IMPORTANT: BEFORE EACH IMPRESSION, CHECK TO MAKE SURE THE EMBOSSEY PLATE IS SECURELY ATTACHED WITHIN THE EMBOSSEY.

If the plate is ***NOT*** securely attached, Pressing harder or using excessive force on the embosser handle can cause the dies to become misaligned or even worse it can cause the die holder to bend causing it to no longer produce a good impression and this will Void the warranty we put on the units.




Once a Seal Insert is Bent this is in NON-Repairable Condition and is not covered under our Seal Warranty!

Tips and Techniques

PRACTICE on scrap paper first. You should feel comfortable determining the amount of pressure needed to make a good impression before you emboss one of your good books or expensive stationery. You should also practice aligning the embosser so your layout appears straight (this is easy with the rectangular plates and a little harder with the circular plates).

PAPER WEIGHT: Embossers are only guaranteed to provide good impressions on standard 20-24lb paper. Embossing heavier paper may result in light or uneven impressions. We do not recommend embossing cardstock heavier than 60lb.
* **Note** Using excessively thick paper or multiple sheets repeatedly may cause damage to your embosser.

ORIENTATION: Make sure to use the embosser along the proper edge of the paper (based on the orientation you chose for that specific embosser plate - Top, Bottom, Left, or Right). Your layout will not appear right-side-up if used along the wrong edge of the paper.



STICKERS/LIGHTWEIGHT PAPER: They may crinkle when you emboss. To minimize, try placing another sheet of regular paper underneath and emboss both together.

SMALL TEARS OR PUNCH-THROUGH: Once in a while using your embosser you might encounter small tears or punch-outs in the paper – These are normal for personal embossers and should not be considered a flaw. To minimize this, try applying less pressure on the handle when embossing. Or, try placing another sheet of regular paper underneath and emboss both together.

Troubleshooting


Uneven Impressions: They may occur for a few reasons - (a) the embosser plate is not securely attached to the embosser, (b) the paper is too heavy, (c) you are not applying enough pressure when embossing...try standing while embossing to get better leverage.



*If you have any problems,
with this please contact us
at (804) 359-0505 or
sales@acornsales.com*

Unlocking The Unit



For Protection purposes the unit is shipped in a locked position, to unlock the embosser follow the following two steps



2) With the handle pushed down (desk model) or the handle squeezed together (pocket model) slide the lock back towards you, which will unlock the unit.


Removing the Insert

1) Unlock the unit as illustrated above





Correct Insert Insertion

1) When Inserting your new plate, bottom slots must be in the notches of the embosser to where it "clicks in"



Reinserting the Insert

1) Reverse Directions as in insert removal





ACORN

SALES COMPANY INCORPORATED


Embosser Operating Instructions

If you have any problems,
with this please contact us
at (804) 359-0505 or
sales@acornsales.com


SEAL INSERTS: When ordering a second seal insert or replacement, you must specify the model so we will know what type of insert to provide. Look at the bottom of the seal insert to match with a model shown below. We make official seals for notaries and professionals in the format required by and U.S. state or jurisdiction. We also produce custom-designed seals for corporate and government offices as well as library and stationery embossers.

** Not all Replacement Inserts are compatible with one another **

Standard Pocket Seal and Soft Seal (Jr. Size)



Top View




Bottom View

This Insert is
Compatible
With




Smaller Pocket Embossers
Standard Size on Most Notary,
Corporate and Stationary Embossers

Standard Desk Seal Insert OR Larger Pocket and Soft Seal (2.0" Diameter)



Top View



Bottom View

This Insert is
Compatible
With




Standard Desk
2.0" Pocket Seals (Larger Handle)

Chrome, Gift and Black Gift Desk Embossers



Top View



Bottom View

This Insert is
Compatible
With



Long Reach Desk Embosser or Official Long Reach Desk Unit



Side View



Bottom View

This Insert is
Compatible
With



* Insert Approximately 4-1/2" from Left to Right

Extended Long Reach Embosser



Side View



Bottom View

This Insert is
Compatible
With




* Insert Approximately 6-1/2" from Left to Right

Motorized Electric Embosser Insert - Perfect Seal Motorized Embosser



Front View



Bottom View

This Insert is
Compatible
With



Compatible Inserts

Not every make and model of embossers will be compatible with one another
for specific questions contact us at (804) 359-0505 or sales@acornsales.com